



\* ALL LOUVER PANELS SHOWN ARE SINGLE LINKAGE.  
IF DOUBLE LINKAGE PER LOUVER PANEL IS REQUIRED,  
ADDITIONAL QUANTITIES OF AFFECTED ITEMS WILL  
BE PROVIDED FOR EACH SET OF LINKAGE.

ITEM	PART DESCRIPTION	DRAWING NUMBER	QUANTITY PER # OF PANELS		TOTAL QUANTITY
			DOUBLE	TRIPLE	
A	JACKSHAFT STAND W/ BEARING	287E3-STD	3	5	
B	REMOVABLE LINKAGE ARM TYPE 'S'	18142-STD	4	7	
C	UNI-CLAMP NO. UM5016-131	25724-STD	3	5	
D	1" DIA. JACKSHAFT TUBE	25722-STD	2	3	
E	JACKSHAFT ADAPTER	32989-STD	1	1	
F	5/16" DIA SWIVEL	A21749	4	6	
G	5/16" DIA. PLATED STEEL CONNECTING ROD	-	2	3	
H	PLATED STEEL MOUNTING SCREWS (#14 x 3/4" LG)	-	8	1E	
I	HONEYWELL ACTUATOR MOUNT	31034-STD	1	1	
J	1/4-20 x 3/4" LG. HEX HEAD	-	2	2	
K	1/4-20 x 1-1/2" LG HEX HEAD	-	3	3	
L	LINKAGE INTERCONNECT	32929-STD	1	2	
M	E-CLIP	-	2	4	

DIMENSION FROM EDGE OF  
SILL TO EDGE OF ACTUATOR  
SETUP IS 7.875.

HONEYWELL ACTUATOR

REVISION	DATE	BY	APPD
<b>abi.</b> air balance, inc. A MESTEK COMPANY 7301 INTERNATIONAL DRIVE HOLLAND, OHIO Phone (419) 885-5000 Fax (419) 885-1375 <b>MULTI-HIGH PANEL            W/ ON BLADE LINKAGE</b>			
CRD BY	JMC	APPD BY	
DATE	02/27/81	DWG. NO.	32769-1-STD
			REV.