



* ALL LOUVER PANELS SHOWN ARE SINGLE LINKAGE.
 IF DOUBLE LINKAGE PER LOUVER PANEL IS REQUIRED,
 ADDITIONAL QUANTITIES OF AFFECTED ITEMS WILL
 BE PROVIDED FOR EACH SET OF LINKAGE.

ITEM	PART DESCRIPTION	DRAWING NUMBER	QUANTITY PER # OF PANELS			TOTAL QUANTITY
			SINGLE	DOUBLE	TRIPLE	
A	JACKSHAFT STAND W/ BEARING	28783-STD	1	2	3	
B	REMOVABLE LINKAGE ARM TYPE 'S'	18142-STD	1	2	3	
C	UNI-CLAMP NO. UM5016-13L	25724-STD	1	1	2	
D	1" DIA. JACKSHAFT TUBE	25722-STD	1	1	2	
E	JACKSHAFT ADAPTER	32989-STD	1	1	-	
F	5/16" DIA SWIVEL	AE1749	2	4	6	
G	5/16" DIA PLATED STEEL CONNECTING ROD	-	1	2	3	
H	PLATED STEEL MOUNTING SCREWS (#14 x 3/4" LG)	-	4	6	8	
I	HONEYWELL ACTUATOR MOUNT	31034-STD	1	1	1	
J	1/4-20 x 3/4" LG. HEX HEAD	-	2	2	2	
K	1/4-20 x 1-1/2" LG. HEX HEAD	-	3	3	4	
L	JACKSHAFT ADAPTER	32995-STD	-	-	1	

DIMENSION FROM EDGE OF
 SILL TO EDGE OF ACTUATOR
 SETUP IS 7.875.

HONEYWELL ACTUATOR

REVISION	DATE	DRN	CHK	APP
abi.		air balance, inc. A MESTEK COMPANY		
7301 INTERNATIONAL DRIVE		HOLLAND, OHIO		
Phone (419) 863-5000		Fax (419) 863-1373		
MULTI-WIDE PANEL W/ ON BLADE LINKAGE				
DRN BY	JMC	APP'D BY		
DATE	02/27/81	DWG. NO.	32769-STD	REV.

5132769